# Installation Guide

1. Connect the (Transmitter side) USB Type-A Male connector to the Host Computer.
2. Connect the RJ45 CAT 5 cable (up to 40m) between the Transmitter and the Receiver.
3. Connect the USB Device to the (Receiver side) USB Type A Female connector.

USB Device   USB AM

Host

Cat.5
(Up to 40M)

Troubleshooting

If you are having trouble with the extension:

1. Try re-plugging each connector
2. Confirm the two Host Computer's USB ports are functional
3. Ensure the USB Device is turned 'ON'
4. Test and confirm the RJ45 CAT5 Patch Cord is functional

Contents

1x transmitter unit USB A/M > RJ45

1x receiver unit USB A/F > RJ45

1x installation guide